



SB – Service Bulletin
SB B8300903 R1

Doc.: B8300903
Edición 1

Hoja: 11 de 16

CODE	TASK NAME IN REV. 1	REV. 1
REV. 0	REV. 1	REV. 1
1.- HUB AND CONE		Frequency
2.1.6 8.1.1	VISUAL INSPECTION OF THE CONE SUPPORT'S STRUCTURE	Six-monthly
2.1.2 8.1.2	VISUAL INSPECTION OF THE CONE'S FIBER PANELS	Annually
8.1.3	VISUAL INSPECTION OF THE MACHINED HUB	Annually
2.1.1 8.1.4	VISUAL INSPECTION OF THE BOLTED JOINTS BETWEEN THE SUPPORT STRUCTURE AND THE CONE	Annually
2.1.1 8.1.5	VISUAL INSPECTION OF THE BOLTED JOINTS BETWEEN THE SUPPORT STRUCTURE AND THE HUB	Annually
2.- BLADES		Frequency
2.2.1 8.2.1	AUDITORY INSPECTION OF EACH BLADE'S AERODYNAMIC NOISE	Six-monthly
8.2.2	AUDITORY INSPECTION OF MECHANICAL NOISE IN EACH BLADE	Six-monthly
8.2.3	VISUAL INSPECTION OF THE BLADE	Six-monthly
8.2.4	VISUAL INSPECTION OF THE BLADE DUST SEALS	Six-monthly
2.2.2 8.2.5	VISUAL INSPECTION OF THE BOLTED JOINT BETWEEN THE BLADE AND BLADE BEARING	Annually
8.2.6	VISUAL INSPECTION OF THE BLADE ROOT	4 years
8.2.7	VISUAL INSPECTION OF BOLTED JOINT BETWEEN EXTENDER AND BLADE (IF APPLICABLE)	Annually
8.2.8	VISUAL INSPECTION OF BOLTED JOINT BETWEEN EXTENDER AND BLADE BEARING (IF APPLICABLE)	Annually
8.2.9	VISUAL INSPECTION OF THE EXTENDER (IF APPLICABLE)	4 years
2.1.4 8.2.10	INSPECTION OF THE LIGHTNING TRANSMISSION SYSTEM'S HAMMERS	Annually
3.- BLADE BEARINGS		Frequency
2.3.2 8.3.1	VISUAL INSPECTION OF THE RETAINERS OF THE BLADE BEARINGS	Six-monthly
2.3.4 8.3.2	LUBRICATION OF THE BLADE BEARINGS	Six-monthly
8.3.3	VISUAL INSPECTION FOR LEAKS IN THE BLADE BEARINGS' LUBRICATORS	Six-monthly
2.3.1 8.3.4	VISUAL INSPECTION OF THE BOLTED JOINT BETWEEN BLADE BEARING AND HUB	Annually
2.4.2 8.3.5	VISUAL INSPECTION OF THE BOLTED JOINT BETWEEN THE PIN SUPPORT AND BLADE BEARING PLATE	Annually
2.4.3 8.3.7	VISUAL INSPECTION OF FASTENING NUT BETWEEN THE PIN END AND THE BLADE BEARING PLATE	4 years
4.- PITCH SYSTEM		Frequency
8.4.7	CHECKING THE ADJUSTMENT OF THE BALLUFS	Annually
2.4.1 8.4.21	VISUAL INSPECTION OF THE BOLTED JOINT BETWEEN THE PITCH CYLINDER SUPPORTS AND THE HUB	Annually
A.9 8.4.22	VISUAL INSPECTION OF PITCH BLOCK PROTECTION SUPPORT BOLTED JOINTS	Annually
8.4.23	CHECK THE OPERATION OF THE EMERGENCY SOLENOID VALVES	Annually
8.4.24	VISUAL INSPECTION OF BOLTED JOINT BETWEEN THE EMERGENCY ACCUMULATOR SUPPORT AND THE HUB	Annually
8.4.25	VISUAL INSPECTION OF THE BOLTED JOINTS BETWEEN THE LEAK TANK AND THE SUPPORT	Annually
8.4.26	VISUAL INSPECTION OF THE BOLTED JOINT BETWEEN THE LEAK TANK SUPPORT AND THE HUB	Annually
2.4.4 8.4.27	VISUAL INSPECTION OF THE PITCH SYSTEM BALL JOINT COVER BOLTS	Annually
5.- MAIN SHAFT		Frequency
2.7.4 8.5.1	LUBRICATING THE MAIN SHAFT'S BEARINGS	Six-monthly
8.5.2	CLEANING OF THE MAIN SHAFT'S GREASE COLLECTION TRAYS	Six-monthly
8.5.3	VISUAL INSPECTION FOR GREASE LEAKS IN THE MAIN SHAFT'S BEARINGS	Six-monthly
2.7.1 8.5.4	VISUAL INSPECTION OF THE BOLTED JOINT BETWEEN THE HUB AND THE MAIN SHAFT	Annually
2.7.2 8.5.5	VISUAL INSPECTION OF THE BOLTED JOINT BETWEEN THE MAIN BEARING HOUSINGS AND THE FRAME	Annually
2.7.6 8.5.6	LUBRICATION OF THE ROTOR'S LOCK BOLTS	Six-monthly
8.5.7	VISUAL INSPECTION OF THE MAIN SHAFT'S BODY	Annually
6.- GEARBOX (OIL)		Frequency
2.9.4 8.6.1	VISUAL INSPECTION OF THE GEARBOX'S OIL LEVEL	Six-monthly
8.6.2	CHECKING FOR ABSENCE OF METAL PARTICLES IN GEARBOX MAGNETIC ROD	Six-monthly
2.9.2 8.6.3	GEARBOX OIL SAMPLE COLLECTION	Six-monthly
2.9.6 8.6.4	INSPECTION AND REPLACEMENT OF THE GEARBOX AIR FILTER	Six-monthly
2.10.3 8.6.5	VISUAL INSPECTION AND CLEANING OF THE GEARBOX EXCHANGERS	Annually
2.10.2 8.6.6	REPLACEMENT OF GEARBOX ON-LINE FILTER	Annually
2.10.5 8.6.7	REPLACEMENT OF GEARBOX OFF-LINE FILTER	Annually
2.10.1 8.6.8	VISUAL INSPECTION FOR LEAKS IN GEARBOX AND LUBRICATION-COOLING SYSTEM	Annually
2.10.6 8.6.9	CHECKING THE GEARBOX PRESSURE SWITCH SETTING (Pos. 9)	Annually
8.6.10	VISUAL INSPECTION OF GEARBOX COOLING SYSTEM'S HOSES	Annually
2.9.5 8.6.11	GEARBOX OIL CHANGE	2 years
7.- GEARBOX (MECHANICAL ELEMENTS)		Frequency
2.8.3 8.7.1	AUDITORY INSPECTION OF THE GEARBOX	Six-monthly
8.7.2	INSPECTION FOR GAPS IN THE GEARBOX DAMPING PACKETS	Six-monthly
2.8.1 8.7.3	VISUAL INSPECTION OF BOLTED JOINT BETWEEN TORQUE ARMS AND FRAME	Annually
2.8.2 8.7.4	VISUAL INSPECTION OF BOLTED JOINT BETWEEN TORQUE ARMS AND GEARBOX	Annually
8.7.5	VISUAL INSPECTION OF THE GEARBOX'S STRUCTURE	Annually
8.- BRAKE SYSTEM		Frequency
2.11.1 8.8.1	INSPECTION OF THE BRAKE PADS	Annually
8.8.3	INSPECTION FOR LEAKS AND BLEEDING THE MAIN BRAKE SYSTEM'S HYDRAULIC CIRCUIT	Annually
2.5.14 8.8.4	CHECKING AND ADJUSTING THE MAIN BRAKE ACCUMULATOR PRE-CHARGE PRESSURE (Pos. 30)	Annually
2.5.17 8.8.5	CHECKING AND ADJUSTING THE MAIN BRAKE'S SAFETY VALVE SETTING (Pos. 33)	Annually
2.5.15 8.8.6	CHECKING AND ADJUSTING THE MAIN BRAKE'S PRESSURE SWITCH SETTING (Pos. 31)	Annually
9.- COUPLING		Frequency
2.12 8.9.1	VISUAL INSPECTION OF THE HIGH SPEED SHAFT COUPLING	Annually

RJ
RJ



SB – Service Bulletin
SB B8300903 R1

Doc.: B8300903
Edición 1

Hoja: 12 de 16

10.. GENERATOR

2.13.3	8.10.1	LUBRICATING THE GENERATORS BEARINGS	Frequency
2.13.5.2	8.10.2	CLEANING THE SLIP RING BODY	Six-monthly
2.13.6	8.10.3	REPLACING THE GENERATOR'S AIR FILTER (IF APPLICABLE)	Six-monthly
	8.10.4	CHECKING FOR WEAR OF PHASE BRUSHES	Six-monthly
	8.10.5	CHECKING FOR WEAR OF GROUND BRUSHES	Six-monthly
A.14	8.10.9	VISUAL INSPECTION OF BOLTED JOINTS BETWEEN GENERATOR AND FRAME	Annually
2.13.8B	8.10.7	VISUAL INSPECTION OF THE STATOR'S TERMINAL BOX	Annually

11.. HYDRAULIC UNIT

2.5.21	8.11.1	INSPECTION OF THE OIL LEVEL IN THE HYDRAULIC UNIT	Frequency
	8.11.2	INSPECTION FOR LEAKS IN THE HYDRAULIC UNIT	Six-monthly
2.5.16	8.11.3	INSPECTION AND ADJUSTMENT OF THE HYDRAULIC UNIT'S SAFETY VALVE (FOS 25)	Annually
A.25	8.11.4	INSPECTION AND REPLACEMENT OF THE HYDRAULIC UNIT'S AIR FILTER	Annually
2.5.12	8.11.5	REPLACEMENT OF THE HYDRAULIC UNIT'S PRESSURE FILTER	Six-monthly
2.5.3	8.11.6	CHECKING AND ADJUSTING PITCH ACCUMULATOR PRE-CHARGE PRESSURE (Pos. 24, 14, 19, 81, 93 and 94)	Annually
	8.11.7	VISUAL INSPECTION OF NACELLE AND ROTOR HYDRAULIC CIRCUIT HOSES	Annually
	8.11.8	VISUAL INSPECTION AND CLEANING OF HYDRAULIC UNIT EXCHANGER (IF APPLICABLE)	Annually
2.5.22	8.11.10	REPLACING HYDRAULIC UNIT OIL	5 years
2.5.2	8.11.11	DRAIN THE HUB'S LEAK TANK	Six-monthly
2.5.1	8.11.12	INSPECTION FOR HYDRAULIC OIL LEAKS IN THE ROTOR	Annually
2.5.6	8.11.13	HUB PRESSURE FILTER REPLACEMENT	Annually
A.13.2	8.11.14	INSPECTION FOR HYDRAULIC OIL LEAKS IN THE ROTARY JOINT	Annually
	8.11.15	INSPECTING AND ADJUSTING PRESSURE SWITCH SETTINGS OF THE PITCH BLOCKS (Pos. 91)	Annually

12.. YAW SYSTEM

2.15.2.4	8.12.1	LUBRICATION OF THE YAW SYSTEM'S SLIDE ELEMENTS	Frequency
2.16.2.5	8.12.2	LUBRICATION OF THE YAW SYSTEM'S RING GEAR	Six-monthly
	8.12.3	INDIRECT MEASUREMENT OF WEAR ON THE YAW SYSTEM'S RADIAL PETS	Six-monthly
2.16.2.2	8.12.4	AUDITORY INSPECTION OF THE YAW SYSTEM	Annually
	8.12.5	VISUAL INSPECTION OF YAW SYSTEM'S PETP WEAR DUST	Six-monthly
	8.12.6	VISUAL INSPECTION OF THE YAW SYSTEM'S RING GEAR	Annually
2.15.5	8.12.7	INSPECTION FOR OIL LEAKS IN GEARS	Annually
A.7	8.12.8	VISUAL INSPECTION OF THE YAW SYSTEM'S TURN-COUNTER	Annually
2.15.1	8.12.9	VISUAL INSPECTION OF BOLTED JOINTS IN THE GEAR MOTORS	Annually
2.16.2.1	8.12.12	VISUAL INSPECTION OF BOLTED JOINT BETWEEN YAW BASE AND TOWER	Annually
	8.12.13	VISUAL INSPECTION OF THE BOLTED JOINT BETWEEN YAW SYSTEM CLAMPS (AND SPACERS) AND THE FRAME	Annually
	8.12.14	VISUAL INSPECTION OF BOLTS OF HORIZONTAL STOP PLATES (PASSIVE YAW SYSTEM ONLY)	Annually
2.16.2.6	8.12.15	INSPECTION FOR LEAKS IN THE YAW SYSTEM'S HYDRAULIC CIRCUIT	Annually
	8.12.16	CHECKING AND ADJUSTING THE YAW BRAKE REDUCTION VALVE'S SETTING	ACTIVE YAW
A.16	8.12.17	CHECKING AND ADJUSTING THE YAW BRAKE ACCUMULATOR PRE-CHARGE PRESSURE (Pos. 107)	Annually
2.16.2.7	8.12.18	CHECKING THE YAW BRAKE'S PRESSURE IN RETENTION MODE	ACTIVE YAW
	8.12.19	VISUAL INSPECTION OF THE POWER CABLE'S LOOPS	Annually
	8.12.26	ADJUSTMENT OF THE MECHANICAL STACKS IN PASSIVE WELLS	Annually
2.15.6	8.12.27	INSPECTION OF OIL LEVEL IN GEARS	2 years
	8.12.29	VISUAL INSPECTION OF THE YAW SYSTEM'S RING GEAR COVERS	Annually

13.. COVER, NACELLE STRUCTURE AND HTK/LTK

8.13.1	VISUAL INSPECTION OF THE DESCENT DEVICE'S SAFETY EYEBOLT	Frequency	
2.18.1	8.13.2	VISUAL INSPECTION OF THE NACELLE'S FIBER COVER	Annually
2.18.2	8.13.3	VISUAL INSPECTION OF THE NACELLE'S ACOUSTIC INSULATION	Annually
	8.13.6	VISUAL INSPECTION OF BOLTED JOINTS BETWEEN NACELLE ROOF PROFILES	Annually
2.18.3	8.13.7	VISUAL INSPECTION OF THE NACELLE ROOF'S HANDRAIL	Each Use
	8.13.8	VISUAL INSPECTION OF THE BOLTED JOINT BETWEEN THE OUTSIDE HANDRAIL AND THE NACELLE ROOF	Each Use
	8.13.12	REPLACING THE TRANSFORMER AIR INLET GRILLE FILTERS (IF APPLICABLE)	Annually
	8.13.13	VISUAL INSPECTION OF THE LTK AIR HEATERS' FASTENING ELEMENTS (IF APPLICABLE)	Annually
2.19.1	8.13.14	REPLACEMENT OF HTK AIR INLET GATE FILTERS (IF APPLICABLE)	Annually
	8.13.16	VISUAL INSPECTION OF DEFLECTOR FASTENING TO COVER PANELS (IF APPLICABLE)	2 years

14.. TOWER

2.27.7	8.14.1	CHECKING THE LAST INSPECTION DATE OF THE LIFELINE	Frequency
A.1	8.14.2	VISUAL INSPECTION OF THE SAFETY SIGNS IN THE TOWER AND NACELLE	Six-monthly
	8.14.3	LIFELINE CONDITION INSPECTION	Annually
2.27.2	8.14.4	VISUAL INSPECTION OF THE BOLTED JOINTS BETWEEN TOWER SECTIONS	Annually
	8.14.5	VISUAL INSPECTION OF THE FLANGE-RING WELD SEAMS ON THE TOWER SECTION JOINTS	Annually
	8.14.6	VISUAL INSPECTION OF THE FOUNDATION SECTION'S FLANGE	Annually
2.27.1	8.14.7	VISUAL INSPECTION OF THE BOLTED JOINT BETWEEN THE FOUNDATION SECTION AND THE LOWER TOWER SECTION	Annually
	8.14.8	VISUAL INSPECTION OF FOUNDATION FOOTING PEDESTAL	Annually
	8.14.9	VISUAL INSPECTION OF THE GAPS BETWEEN THE FOUNDATION SECTION AND THE FOUNDATION FOOTING'S PEDESTAL	Annually
	8.14.11	VISUAL INSPECTION OF THE TOWER ACCESS DOOR'S HINGES	Annually
	8.14.12	INSPECTION AND REPLACEMENT OF THE TOWER ACCESS DOOR FILTER (IF APPLICABLE)	Annually
2.27.3	8.14.15	VISUAL INSPECTION OF WELDED SEAMS ON THE FRAME OF THE TOWER ACCESS DOOR	Annually

15.. GROUNDING SYSTEM

2.30.3	8.15.1	INSPECTION OF THE GROUND CABLES BETWEEN TOWER SECTIONS	Frequency
	8.15.2	VISUAL INSPECTION OF THE TRANSFORMER GROUND CABLE	Annually
	8.15.3	VISUAL INSPECTION OF THE HIGH VOLTAGE SWITCHGEAR'S GROUND CABLE	Annually
	8.15.4	VISUAL INSPECTION OF THE GROUND CABLES IN THE FOUNDATION	Annually

16.. EMERGENCY SERIES

	8.16.1	INSPECTION OF THE EMERGENCY BUTTONS	Frequency
2.29.3	8.16.2	CHECKING THE OGS RELAY'S OPERATION	Six-monthly
	8.16.10	CHECK THE OPERATION OF TOP NON-EMERGENCY KR910 RELAY	Annually

17.. BASTIÖR

2.6.1	8.17.1	VISUAL INSPECTION OF THE FRAME	Frequency
2.6.2	8.17.2	VISUAL INSPECTION OF THE BOLTED JOINTS BETWEEN THE FRONT AND REAR FRAMES	Annually

10.- TRANSFORMER AND SWITCHGEAR

- 8.18.1 VISUAL INSPECTION OF THE TRANSFORMER NEUTRAL CABLE (LOW VOLTAGE SIDE)
- 8.18.2 VISUAL INSPECTION OF THE TRANSFORMER'S FASTENERS
- 8.18.3 CHECKING THE HIGH VOLTAGE SWITCHGEAR'S MANUAL MANEUVERS
- 8.18.7 CHECKING THE OPERATION OF THE SWITCHGEAR TRIP BUTTON (A60) IN TOP
- 8.18.8 CHECKING THE OPERATION OF THE TRANSFORMER FUSE MICROSWITCHES
- 8.18.9 VISUAL INSPECTION OF THE TRANSFORMER'S AUTOMATIC VALVES
- 8.18.10 CHECKING THE SWITCHGEAR TRIP THROUGH LEAK TO NEUTRAL RELAY
- 8.18.11 CHECKING THE ELECTRIC ARC DETECTOR RELAY'S OPERATION
- 8.18.12 CHECKING THE OPERATION OF THE LIMIT SWITCHES ON TRANSFORMER ACCESS DOORS
- 8.18.13 VISUAL INSPECTION OF THE TRANSFORMER'S CABLES, TERMINALS AND LV FUSES
- 8.18.14 VISUAL INSPECTION OF THE TRANSFORMER'S TERMINALS AND HV DELTA CONNECTION
- 8.18.15 TRANSFORMER CLEANING AND FINAL CHECKS

Frequency

- Annually To be carried out by authorized staff
- Annually To be carried out by authorized staff
- Annually To be carried out by authorized staff
- Annually To be carried out by authorized staff
- 2 years To be carried out by authorized staff
- Annually To be carried out by authorized staff
- Annually To be carried out by authorized staff
- Annually To be carried out by authorized staff
- Annually To be carried out by authorized staff
- Annually To be carried out by authorized staff
- Annually To be carried out by authorized staff
- Annually To be carried out by authorized staff

19.- LIGHTING

- 8.19.2 INSPECTION OF THE EMERGENCY LIGHTS IN THE TOWER
- A.10 8.19.3 INSPECTION OF THE BEACON SYSTEM
- 8.19.4 INSPECTION OF THE BEACON SYSTEM'S UPS (IF APPLICABLE)

Frequency

- 2 years
- Annually Or After a storm
- 2 years

20.- SMP

- 2.32.2 8.20.1 VISUAL INSPECTION OF THE SMP'S OPERATION
- 2.32.8 8.20.2 INSPECTION OF SMP GROUND CONNECTIONS
- 2.32.6 8.20.3 VISUAL INSPECTION OF THE SMP ACCELERATORS
- 2.32.1 8.20.4 DOWNLOADING DATA FROM THE SMP TO ANALYZE VIBRATIONS

Frequency

- Six-monthly
- Six-monthly
- Six-monthly
- Six-monthly

21.- HOIST

- 8.21.1 BRAKE OPERATION CHECK
- 8.21.2 VISUAL INSPECTION AND CHAIN LUBRICATION
- 8.21.3 LOAD LIMITER OPERATION CHECK
- 8.21.8 VISUAL INSPECTION OF THE HOIST CHAIN'S MECHANICAL END STOP
- 8.21.9 VISUAL INSPECTION OF THE HOIST'S EMERGENCY BUTTON
- 8.21.10 VISUAL INSPECTION OF THE HOIST'S SAFETY HOOK AND TAB
- 8.21.11 VISUAL INSPECTION OF THE HOIST'S CHAIN GUIDE ELEMENTS
- 8.21.12 VISUAL INSPECTION OF THE HOIST CHAIN'S SAFETY ANCHOR
- 8.21.13 CHECKING FOR THE PRESENCE OF THE HOIST BRAKE SAFETY SEAL
- 8.21.15 VISUAL INSPECTION OF THE HOIST CHAIN'S BAG AND ITS SUPPORT
- 8.21.16 VISUAL INSPECTION OF THE BRIDGE CRANE FRAME
- 8.21.17 VISUAL INSPECTION OF THE BRIDGE CRANE TROLLEY'S WELDED STRUCTURE
- 8.21.18 VISUAL INSPECTION OF THE HOISTING NOISE

Frequency

- Annually
- Annually
- Annually
- Annually
- Each Use
- Each Use
- Each Use
- Each Use
- Each Use
- Annually
- Annually
- Annually
- Annually

22.- OTHERS

- 8.22.1 MACHINE CLEANING
- 2.24.1 8.22.2 CHECKING LAST INSPECTION DATE OF GROUND EXTINGUISHER (IF APPLICABLE BY CONTRACT)
- 2.24.2 8.22.3 CHECKING LAST INSPECTION DATE OF NACELLE EXTINGUISHER (IF APPLICABLE BY CONTRACT)
- A.5 8.22.5 CHECKING LAST INSPECTION DATE OF NACELLE EMERGENCY DESCENT DEVICE

Frequency

- Six-monthly
- Six-monthly
- Six-monthly
- Each Use

23.- PLC

- 8.23.1 CHECKING THE OPERATION OF THE SMOKE DETECTOR
- 2.17.2.1 8.23.2 CHECKING THE NRG SYSTEM

Frequency

- 2 years
- 2 years

24.- AVANTI ELEVATOR

- 8.24.1 CHECKING BLOCSTOP DEVICE OPERATION
- 8.24.2 INSPECTION AND CHECKING THE OPERATION OF THE LOWER LIMIT SWITCH
- 8.24.3 INSPECTION AND CHECKING THE OPERATION OF THE UPPER LIMIT SWITCH LEVER
- 8.24.4 VISUAL INSPECTION OF THE DRIVE CABLE GUIDES
- 8.24.5 VISUAL INSPECTION OF GUIDE CABLES
- 8.24.6 VISUAL INSPECTION OF THE HOISTING CABLES
- 8.24.7 VISUAL INSPECTION OF THE SAFETY CABLE
- 8.24.8 VISUAL INSPECTION OF THE DCJAW JOINT SLACKLES
- 8.24.9 VISUAL INSPECTION OF THE ELEVATOR'S SUPPORT BEAM
- 8.24.10 VISUAL INSPECTION OF ELEVATOR SUPPORT BEAM-TOWER BOLTED JOINTS
- 8.24.11 VISUAL INSPECTION OF THE ELEVATOR'S SAFETY SIGNS
- 8.24.12 CHECK LOAD LIMITER OPERATION
- 8.24.13 INSPECTION OF THE ELEVATOR'S EMERGENCY BUTTONS
- 8.24.14 VISUAL INSPECTION OF ANCHORING POINTS INSIDE THE ELEVATOR CABIN
- 8.24.16 ELEVATOR MOTOR BRAKE INSPECTION

Frequency

- Each Use
- Annually
- Annually
- Annually
- Annually
- Annually
- Annually
- Annually
- Annually
- Annually
- Annually
- 2 years
- Each Use
- Each Use
- Annually

25.- OMEGA ELEVATOR

- 8.25.1 VISUAL INSPECTION OF THE HOISTING CABLES
- 8.25.2 VISUAL INSPECTION OF GUIDE RAILS
- 8.25.3 VISUAL INSPECTION OF GUIDE SUPPORT PROFILES
- 8.25.4 VISUAL INSPECTION OF THE UPPER PULLEY AND BEAM FASTENING
- 8.25.5 VISUAL INSPECTION OF THE LIMITER'S DAMPERS
- 8.25.6 VISUAL INSPECTION OF GUIDE SLIDING WHEEL
- 8.25.7 ELEVATOR BRAKE OPERATION CHECK AND INSPECTION
- 8.25.8 INSPECTION AND CHECKING THE OPERATION OF THE UPPER LIMIT SWITCH
- 8.25.9 INSPECTION AND CHECKING THE OPERATION OF THE LOWER LIMIT SWITCH
- 8.25.10 VISUAL INSPECTION OF THE ELEVATOR'S SAFETY SIGNS
- 8.25.11 VISUAL INSPECTION OF THE ELEVATOR'S SAFETY CATCH LEVER
- 8.25.12 INSPECTION OF THE ELEVATOR'S EMERGENCY BUTTONS

Frequency

- Annually
- Annually
- Annually
- Annually
- Annually
- Annually
- Annually
- Annually
- Annually
- Annually
- Each Use
- Each Use

26.- CONVERTER AND ELECTRICAL CABINETS

- 8.26.1 INSPECTION OF GROUND CABINET OVERVOLTAGE DISCHARGERS (ONLY DFM)
- 2.14 8.26.2 VISUAL INSPECTION OF CONVERTER COOLING HOSES (DFM ONLY)
- 8.26.3 INSPECTION AND CLEANING OF CONVERTER COOLING EXCHANGER (DFM ONLY)
- 2.26 8.26.4 REPLACEMENT OF THE CONVERTER'S AIR FILTERS (DTC ONLY)
- 8.26.5 REPLACEMENT OF FAN AIR FILTERS IN ELECTRICAL CABINETS

Frequency

- Annually DFM
- Annually DFM
- Annually DFM
- Annually DTC
- Annually

If this master of tasks is changed by the customer, those changes will be recorded on corresponding Annex D.

Note: This Preventive Rev 1 was created once the RCM study of the Wind Turbine's systems was completed, which means there are many changes compared with Rev 0. Due to the high number of changes, it was considered impractical to include those changes in this document even though in subsequent revisions, changes will be introduced since they there will not be as many of them.

R5
B