



---- Recinzione ---- SSE TERNA Viabilita — Cabine_e_servizi Cavidotto MT --- Moduli_FV Cavidotto AT --- SE TERNA Pendenza dei versanti (°) 0 - 2 3 - 4 5 - 6 7 - 8 9 - 10 11 - 12 13 - 14 15 - 16 17 - 18 19 - 20 21 - 22 23 - 24 25 - 26 27 - 28 29 - 30 31 - 32 33 - 34 35 - 36 37 - 38

Legenda:

0 625 1.250 2.500 3.750 5.000

1:25.000

39 - 40